
STANDARD A-FRAME

SIGN INSERTION INSTRUCTIONS



SET UP

Slide sign down through the tabs



Slide through, pulling sign in front of bottom slot until sign hits the ground



3 Push sign up into top slot




Slide sign down into bottom slot



SAND FILLING INSTRUCTIONS

- The Standard A-Frame has two fill holes for sand, one on each half of the sign frame.
- Remove plug from fill hole and fill the hole with dry sand, 3 lbs. of sand per hole maximum, for a total of 6 lbs. per sign frame is recommended.
- Play sand is suggested for ease of filling.



SIGN RIDER INSTRUCTIONS

- Stand the sign frame on the ground, spreading open the sign faces only half way. Place the Sign Rider in the hinge openings between the sign faces. Now, move the sign faces apart until fully extended. The hinges will "grab" the Sign Rider.
- For a more stable/permanent rider installation, drill holes into the rider to match up with the pins on the grabber hinge. Velcro[®] dots can also be used.





Hinges

Hinge Opening Aerial View

CARE AND MAINTENANCE

- For long lasting durability and the best possible protection for your E-Z UP® products, follow these E-Z care and maintenance instructions:
- Use a mild soap (not detergent) and plenty of water for cleaning the frame.
- Let the frame dry completely before closing or storing to avoid mildew. **CONDITIONS**

This warranty shall be void as to any product that has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberate damage of the product, nor to the use of the product that does not conform with the product instructions. This warranty is provided in lieu of all other warranties, expressed or implied.

IMPORTANT INFORMATION

READ THIS INFORMATION BEFORE PROCEEDING. IT IS THE USER'S RESPONSIBILITY TO TAKE THE FOLLOWING PRECAUTIONS AT ALL TIMES.

- Always stake or weigh down your E-Z UP® product with genuine E-Z UP® accessories. Do not use in any potentially windy or rainy weather.
- Wind and rain can damage the E-Z UP® product and also may result in injury to you or others.
- Use caution when handling the frame.
- Avoid pinching hands or fingers as frame opens or closes.

© Copyright 2022 International E-Z UP, Inc. USA. All rights reserved.